How do I reset a malfuctioning Motorola Pager (American Messaging)

1. Take out AA battery
2. Put in the battery in reverse direction
3. Wait 10 seconds
4. Put battery back in the normal direction
5. This will reset the pager

Revision #2
Created Thu, Apr 14, 2011 12:09 AM by Lee, Mike
Updated Fri, Feb 15, 2013 6:55 PM by Lee, Mike