How do I reset a malfuctioning Motorola Pager (American Messaging)

1. Take out AA battery
2. Put in the battery in reverse direction
3. Wait 10 seconds
4. Put battery back in the normal direction
5. This will reset the pager

Revision #2
Created 2011-04-14 00:09:20 UTC by Lee, Mike
Updated 2013-02-15 18:55:33 UTC by Lee, Mike