

# Install Windows on a Computer with ICH9R RAID

This solves the problem where the Windows installation will say “Cannot find IASTOR.sys” during the file copy process (but sees the hard drive partitions initially).

If you already made a floppy with drivers using utility:

1. Create folder \$OEM\$ on a floppy with drivers.
2. Create folder TEXTMODE in folder \$OEM\$, so structure will look like \$OEM\$\TEXTMODE
3. Copy files (not move, but copy!)
  - iaahci.cat
  - iaahci.inf
  - iastor.cat
  - iastor.inf
  - iastor.sys
  - txtsetup.oem

to the folder TEXTMODE.

Now Windows Setup will find all files fine.

---

Revision #1

Created Thu, Apr 29, 2010 5:05 PM by Nguyen, Dave

Updated Thu, Apr 29, 2010 5:05 PM by Nguyen, Dave